

Easy-UPS SRV firmware upgrade

Power on the UPS

If the UPS is OFF (its display is completely off) plug the power cord to the input socket of UPS, and wait a moment for the UPS to enter STANDBY mode. In standby mode, the output is off.



Plug in the power cord

Firmware Upgrade

Refer to the table below to select the correct firmware accordingly.

Model	SKU	firmware file
India RACK	SRV3KL-IN	36-002656-01s1.mot
Global RACK	SRV3KRA, SRV3KRA-TW,SRV3KRI, SRV3KRI-AR, SRVS3KRI, SRV3KRI-TW	36-002449-03s1.mot
Global Tower	SRV3KA, SRV3KA-TW, SRV3KI, SRVPM3KIL, SRV3KI-AR, SRV3KI-BR, SRVS3KI, SRV3KI-TW, SRVPM3KIL-AR, SRVPM3KIL-BR, SRVS3KI-AZ, SRVSPM3KIL	36-002287-05s1.mot





Firmware Upgrade

3.1. Extract the compressed package “Update firmware and software” with password: 111 in the computer. Use the supplied RS-232 cable to connect the UPS and the Computer.


3.2. Double click  UPSReflashTool v00.09.exe in folder of UPSReflashTool to run the software. Select the COM port used in the listbox **Interface**. **COM:**

3.3. Click the **File** button to select the firmware (*.mot) and click “open” button to open the firmware file.

3.4. Click the **Update Firmware** button to update the firmware. After the firmware update success, the following figure will be show. Click OK to finish the updating.



Note: Before start the firmware updating, please check if the COM port is used by other software (for example: monitor software), if so, you must stop the agent service of monitor software.




Version Check

Refer to the table below, to check the firmware version:

Model	SKU	firmware version
India RACK	SRV3KL-IN	00.4
Global RACK	SRV3KRA, SRV3KRA-TW, SRV3KRI, SRV3KRI-AR, SRVS3KRI, SRV3KRI-TW	00.4
Global Tower	SRV3KA, SRV3KA-TW, SRV3KI, SRVPM3KIL, SRV3KI-AR, SRV3KI-BR, SRVS3KI, SRV3KI-TW, SRVPM3KIL-AR, SRVPM3KIL-BR, SRVS3KI-AZ, SRVSPM3KIL	00.9

Version Check

<p>4.1. After firmware was updated, Press  button and press  2 times.</p>	<p>4.2. Press the  then go to "UPS" menu, navigate between the menu options.</p>	<p>4.3. The firmware version is 00.9. If not, the upgrading may be failed or not executed.</p>	<p>4.4. Press  2 times to return to the initial status.</p>
   	  	 	 

Life Is On



Schneider
Electric

