



To install the gasket on a Vertical Exhaust Duct Kit the key points to follow are:

- Thoroughly clean surface with an alcohol wipe.
- Use lint free cloth for alcohol wipe. You should be able to get these at a paint store or possibly Home Depot.
- Ensure the surface is completely dry. Remove only the first few inches of backing to get the gasket going and then continue to remove the backing as you go.
- If you remove the entire backing at the beginning, you risk contaminating the adhesive.
- Use roller as shown in instruction video. Pressure applied needs to be 30lb/inch which is firmly pressing.
- You must wait 24 hours for the adhesive to set before compressing or otherwise stressing the gasket.
- If you remove the gasket for any reason, even to reposition it, it should be discarded and a new piece should be used, repeating the cleaning process.

This link has a good video showing how to install the gasket:

<https://www.trimlok.com/rsinstall>