

Product data sheet

Specifications



Service, EcoFit Life Extension Essential, RM6, cubicle CB thermal sensor installation TH110

FSRACORM6TH110

⚠ Discontinued on: Nov 8, 2023

⚠ Discontinued

Main

Product Or Component Type	Service
Lifecycle Service	Modernisation - Asset Connect
Period Of Intervention	Standard working hours
Sensor Type	9 x thermal sensor TH110
Service Description	Installation on cable connection Pairing with SMD Cubicle upgrade Sensors installation in cubicle Functional testing
Service Benefits	24/7 connection temperature monitoring
Terms And Conditions	Local terms and conditions apply
Service Use Conditions, Context And Limits	All equipment to be served is de-energised Access to all necessary site locations and facility documentations Safe workspace Check sensors compatibility with the cubicle Check if adaptation kit is needed Mandatory to add SMD receiver
Excluded Services	Fire suppression Physical security Structural analysis SMD receiver is not included Repair of damage due to abuse, misuse, lack of maintenance Any specialised testing
Range Of Product	EcoFit Life Extension Essential

Complementary

Range Compatibility	RM6
---------------------	-----

Packing Units

Unit Type Of Package 1	PCE
Number Of Units In Package 1	1

Disclaimer: This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications