


Restoring the default password for SNMP/WEB card # 66074

If you lose your password, to restore the default one MGEUPS, you must perform following steps:

- Pull out the card from the UPS slot.
- Move jumper as shown below.
- Insert the card inside the UPS slot and wait for 30 seconds.
- Pull out the card from the UPS slot again.
- Move jumper to the original position shown below.
- Insert the card inside the UPS slot, secure it, and wait for 30 seconds
- Password is now reset to MGEUPS. You can customize it again.



Remark. When the jumper is not returned to its original position, MGEUPS password is restored every time the card is restarted.

