


Frame Difference: NetShelter HS vs. SX

The toolless mounting holes on the backside of the frame of the NetShelter HS have been removed. See below:



HS Frame – No toolless holes on the backside of the frame.



SX Frame – Toolless holes on the backside of the frame.